INSTRUCTION MANUAL


III. Operation Notice


- The product is used at cold water temperature 4~29°C, hot water temperature 45~85°C and water pressure 0.05~1.0 MPa. Please avoid large pressure difference between hot and cold water. The thermostatic cartridge is preferably in use under the condition of water pressure 0.3 MPa, cold water 15°C, hot water 65°C. Main valve should be equipped with a filter.
- 2. To avoid using the faucet as hand rail, a separate hand rail must be installed if needed. Do not hang heavy objects on the mixer.
- 3. Make sure the faucet is off when no water comes out of it, especially when nobody resides in or during the period of decoration or suspension of water.
- 4. Regularly clean the surface of faucet to keep it bright. Attention: Do not use inappropriate tools such as sharp brushes, rough sponges, scouring pads or corrosive detergent to clean the faucet. It is not recommended to use the detergent sold in the market, because its formula changes frequently. Please clean the faucet with wet cloth and soapy water after usage. Then rinse the soap off with clean water and dry with a soft cotton cloth.
- 5. Residues of shampoo, shower gel, hair dye, perfume, shaving water, nail polish, toothpaste and other substances may cause damage to the product. Please carefully rinse residues with clean water after use. Also, do not store detergents and chemicals under the product, such place as vanity cabinet of washbasin; otherwise volatile gases will damage the product.
- 6. When room temperature falls below 0°C, take necessary measures (keep the product warm, close windows) to prevent the product from frost cracking, especially when windows open for air ventilation while nobody in the house.
- 7. Turn on the cold water first, then hot water. Adjust the temperature before use to avoid scald.
- 8. Children, adults with mental disorders should not be allowed to use the shower system without supervision, nor should people affected by alcohol or drugs.
- Sensitive parts of the body, such as eyes, must be kept out of water flows from shower head and sufficient distance between shower head and human head is needed.
- 10. Do not disassemble the product without help from the professionals.


BS83712115


I. Installation Notice


- 1. Install water pipes in accordance with this manual.
- 2. Floor drain should be installed on the site.
- All the components except mixer body should be installed only after the completion of house interior decoration in case paint or other chemicals erode the mixer surface.
- Run water to clean pipes so as to get rid of mud, sand or other debris blocked in pipes before installation.
- 5. If the thread does not match well with the water pipe, please identify the cause first; otherwise a forced connection will damage the product.
- 6. After installation, check all the joints to ensure they are firmly connected. Turn on and off the water repeatedly to ensure there is no leakage around the joints. After that, the product is ready for normal use.
- 7. Keep the manual to users.





















V. Maintenance(Diagram43-46):

If the flow rate is lessened or temperature control is imprecise after a period of usage, it is possibly because water of poor quality blocks the filter of the thermostatic cartridge. Cleaning method should be taken as shown in Diagram 43: First, use suction cup to suck the screw cover. Remove the followings one by one: M4 screw, thermostatic handle and cover plate. Tighten the stop with a slotted screwdriver to turn off the water. Then remove the stop collar, lock sleeve, extended sleeve and cartridge spindle. Take out the thermostatic cartridge and clean the filter part with a brush and vinegar. Then assemble them back accordingly. After that, install the stop back to the initial position to turn on the water, and put back the cover plate and thermostatic handle in turn. Pay attention to keeping the four parts on one line: the slot on the thermostatic cartridge, stop collar, safety button on the thermostatic handle and the 38°C mark on the cover plate.

44

If water flow from the handshower is lessened or does not spray evenly after a period of usage, it is possibly because debris or limescale blocks the filter or nozzles. Please clean the filter and nozzles as shown in Diagram 44. If water flow from the rainshower does not spray evenly, or no water comes out of some nozzles, it is possibly because debris or limescale blocks nozzles. Please gently squeeze those rubber nozzles with fingers as shown in Diagram 45and clean up the debris. If the volume from the handshower is normal, but the volume from the rainshower reduces, it is possibly because water of poor quality blocks the filter. Please take out the filter as shown in diagram 46 and assemble it back after cleaning with brush and vinegar.



S2 wrench

